



Parafos® TEST INSTRUCTIONS **(CUBE METHOD, 0-5 ppm Parafos®)**

1. Rinse the empty colour cube with the water to be tested. Fill to the mark with the water sample.
2. Open one PhosVer 3 **Parafos®** powder pillow and add the contents to the cube. Cap the cube and invert several times to mix.
3. Allow 1 minute, but not more than 2 minutes, for colour development.
4. Match the colour of the sample to the closest colour on the cube to obtain residual level of **Parafos®**.
5. Maintain a **Parafos®** level as recommended by your Keytech representative.

EQUIPMENT & REAGENTS **TEST KIT NO. OTK062**

- (1) **Parafos®** colour cube, #12505
- (40) 5 mL PhosVer 3 **Parafos®** powder pillows (Reorder Code OPPPAR)