



Parafos® TEST INSTRUCTIONS **(COMPARATOR METHOD, 0-5 ppm Parafos®)**

1. Fill each comparator tube to the first line with 5 mL of the water to be tested.
2. Place one tube in the left top opening of the colour comparator box.
3. To the other tube, add the contents of one PhosVer 3 **Parafos®** powder pillow and swirl to mix.
4. Place this tube in the right top opening of the colour comparator box.
5. Allow 1 minute, but not more than 2 minutes, for colour development.
6. Hold the comparator up to a light source (natural if possible). Look through the openings in the front of the colour comparator box.
7. Rotate the colour disc until the colour matches in the two openings.
8. **Divide** the reading by **10** to obtain residual level of **Parafos®**.
9. Maintain a **Parafos®** level as recommended by your Keytech representative.

EQUIPMENT & REAGENTS **TEST KIT NO. OTK063**

- (2) Comparator tubes, #46600-04
- (1) Colour comparator box, #1732
- (1) Colour Comparator Disc, #24898-00
- (40) 5 mL PhosVer 3 **Parafos®** powder pillows (Reorder Code OPPPAR)