



## **Parafos® GAMMA TEST INSTRUCTIONS** **(CUBE METHOD, 0-10 Parafos® Gamma Index)**

1. Rinse the empty colour cube with the water to be tested. Fill to the mark with the water sample.
2. Open one PhosVer 3 **Parafos®** powder pillow and add the contents to the cube. Cap the cube and invert several times to mix.
3. Allow 1 minute, but not more than 2 minutes, for colour development.
4. Match the colour of the sample to the closest colour on the cube.
5. **Multiply** the reading by **2** to obtain the **Parafos®** Gamma Index.
6. Maintain a **Parafos®** Gamma Index as recommended by your Keytech representative.

### **EQUIPMENT & REAGENTS** **TEST KIT NO. OTK065**

- (1) **Parafos®** Colour cube, #12505
- (40) 5 mL PhosVer 3 **Parafos®** powder pillows (Reorder Code OPPPAR)