



Parafos® TEST INSTRUCTIONS **(CUBE METHOD, 0-10 ppm Parafos®)**

1. Fill the test tube to the 5 mL mark (first line) with the water to be tested. Add deionized water to the 10 mL mark (second line). Cap with stopper. Invert to mix.
2. Rinse the empty color cube with deionized water. Fill the color cube to the mark with the water from the test tube.
3. Open one PhosVer 3 **Parafos®** powder pillow and add the contents to the cube. Cap the cube and invert several times to mix.
4. Allow 1 minute, but not more than 2 minutes, for color development.
5. Match the color of the sample to the closest color on the cube.
6. **Multiply** the reading by **2** to obtain residual level of **Parafos®**.
7. Maintain a **Parafos®** level as recommended by your Keytech representative.

EQUIPMENT & REAGENTS **TEST KIT NO. OTKU66**

- (1) Test tube, 1730
- (1) **Parafos®** color cube, #12505
- (40) 5 mL PhosVer 3 **Parafos®** powder pillows (Reorder Code OPPUPO)
- (1) 225 mL bottle deionized water